

LED PWM Dimmer

Installation instructions

WARNING: These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes and/or the current National Electric Code (NEC). For installation in a standard wall box designed for use with wall dimmers and wall switches.

PLEASE READ THE FOLLOWING CAREFULLY BEFORE PROCEEDING!

CAUTION - To reduce risk of fire, electric shock or injury to persons:

1. **BE SURE THAT SUPPLY POWER IS DISCONNECTED AT THE SOURCE BEFORE PROCEEDING!**
2. **DO NOT OPEN THE DIMMER OR ATTEMPT TO SERVICE - THIS COULD CREATE A SHOCK HAZARD AND/OR DAMAGE THE DEVICE!**
3. **DO NOT CONNECT 120V AC POWER TO THIS DEVICE. IT MUST BE POWERED ONLY BY 12V OR 24V DC (CONSTANT VOLTAGE) POWER.**
4. For all wire-to-wire connections, use UL Listed wire nuts.
5. Do not exceed 6 amps of load connected directly to the dimmer.

LEDsupply
FOR ALL YOUR LED PROJECT NEEDS

LED PWM Dimmer

Installation instructions

WARNING: These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes and/or the current National Electric Code (NEC). For installation in a standard wall box designed for use with wall dimmers and wall switches.

PLEASE READ THE FOLLOWING CAREFULLY BEFORE PROCEEDING!

CAUTION - To reduce risk of fire, electric shock or injury to persons:

1. **BE SURE THAT SUPPLY POWER IS DISCONNECTED AT THE SOURCE BEFORE PROCEEDING!**
2. **DO NOT OPEN THE DIMMER OR ATTEMPT TO SERVICE - THIS COULD CREATE A SHOCK HAZARD AND/OR DAMAGE THE DEVICE!**
3. **DO NOT CONNECT 120V AC POWER TO THIS DEVICE. IT MUST BE POWERED ONLY BY 12V OR 24V DC (CONSTANT VOLTAGE) POWER.**
4. For all wire-to-wire connections, use UL Listed wire nuts.
5. Do not exceed 6 amps of load connected directly to the dimmer.

LEDsupply
FOR ALL YOUR LED PROJECT NEEDS